multitek



PowerRelay The combination transducer relay

POWER RELAY

The M570-PR* PowerRelay is a combination of multifunctional relay and AC power transducer. The RS485 communication port provides Modbus output of all parameters measured and allows programming of the 4 relays as well as programming of CT and VT ratios, demand times etc.

RELAY SETUP

The M570-PR* PowerRelay Setup allows programming of the 4 independent relays and any 8 parameters out of 18 assignable can be assigned to 3 of these relays. Each relay has adjustable parameters, such as set point, time delay etc. The 4th relay is an option and can be used for pulsed output for W.h VAr.h VA.h A.h

Parameters 20 different parameters can be assigned to the relays. **Relay Mode** The relay can be assigned so that it operates as an over, under or window type. Trip (% Range) The trip-point (setpoint) can be adjusted between 10 and 120% of nominal input.

Reset (% Range) The reset (differential) can be adjusted between 1 and 120% of nominal input.

Relay Setup							X
Parameter 1	Parameter 2	Parameter 3	Parameter 4	Parameter 5	Parameter 6	Parameter 7	Parameter 8
Assignment	Assignment	Assignment	Assignment	Assignment	Assignment	Assignment	Assignment
V (Volts) V	A (Amps)	Hz (Frequenc 💌	W (Power)	VAr (Reactive 💌	-W (Reverse 💌	-VAr (Rev.VAr 💌	Vbal (V Balan 👻
Relay Mode	Relay Mode	Relay Mode	Relay Mode	Relay Mode	Relay Mode	Relay Mode	Relay Mode
Over 💌	Under 💌	Windov 💌	Over 💌	Under 💌	Over 💌	Under 💌	Windov ▼
Setpnt (% Range)	Setpnt (% Range)	Centre (% Range)	Setpnt (% Range)	Setpnt (% Range)	Setpnt (% Range)	Setpnt (% Range)	Centre (% Range)
110	85	100	105	95	110	80	100
Diff (% Range)	Diff (% Range)	+/-(% Range)	Diff (% Range)	Diff (% Range)	Diff (% Range)	Diff (% Range)	+/- (% Range)
2	2	5	1	1	2	2	10
Group Logic	Group Logic	Group Logic	Group Logic	Group Logic	Group Logic	Group Logic	Group Logic
Averagi	Any 1 💌	Any 1 💌	Sum 💌	Sum 💌	Any 3 💌	Sum 💌	Any 1 💌
Time Delay	Time Delay	Time Delay	Time Delay	Time Delay	Time Delay	Time Delay	Time Delay
5.0 s	10.0 s	2.0 s	10.0 s	10.0 s	5.0 s	15.0 s	5.0 s
Attach To Relay	Attach To Relay	Attach To Relay	Attach To Relay	Attach To Relay	Attach To Relay	Attach To Relay 3	Attach To Relay
Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled
Range 0-230.00V (0-100%). 5% = 11.50V	Range 0-400.00A (0-100%). 5% = 20.00A	Range 40-60Hz (0-100%). Mid range 50Hz (50%) 5% = 1Hz	Range 0-276.00kW (0-100%). 5% = 13.80kW	Range 0-276.00kVAr (0-100%). 5% = 13.80kVAr	Range 0 to -92.00kW (0-100%). 5% = 4.60kW	Range 0 to -276.00kVAr (0-100%). 5% = 13.80kVAr	Range 0-230.00V (0-100%). 5% = 11.50V
Setpoint = 253.00V Differential = -4.60V	Setpoint = 340.00A Differential = 8.00A	0% = 112 Centre Point = 60.00Hz Window (+/-) = 1.00Hz	Setpoint = 289.80kW Differential = -2.76kW	Setpoint = 262.20kVAr Differential = 2.76kVAr	Setpoint = -101.20kW Differential = 1.84kW	Setpoint = -220.80kVAr Differential = -5.52kVAr	
Relay # Type 1 Operate Help OK Cancel							

Group Logic Allows the relay to trip on 1, 2, 3 phases, the sum or the average of the systems assigned parameter when limits are reached. Time Delay The time delay can be set between 40msec to 2 minutes in 1 second steps. Attach to Relay The parameter can be attached to relay 1, relay 2 or relay 3. **Relay Action** The relay can be programmed to energise on trip or de-energise on trip.

PULSED OUTPUT RELAY

The fourth relay is an option and is used as an energy relay providing a pulse output corresponding to either Watt hour Import or Export, VAr hour Import or Export, VA hour or Ampere hour. Pulse width can be selected as well as the relay divisor which allows relay to pulse every 1, 10 or 100 counts.

RELAYS STATE

The free set up and monitor software allows monitoring of the state of each relay as well as indicating the parameters assigned. See below the exceptions screen.



SYSTEM MONITOR

The System Monitor program displays all 42 parameters being measured. CT and VT ratios demand times, etc. all can be set via this program. The System Monitor enables programming of the 4 relays as well as data logging. System Monitor is free and contains help files and operating instructions. It can be downloaded from Multitek website: www.multitek-ltd.com

COMMUNICATION

PowerRelay uses RS485 Modbus protocol. This enables remote reading and programming of the PowerRelay via a host computer. The RS485 allows up to 32 PowerRelays to be connected in parallel, allowing them to be used with PC, PLC, RTU, Data loggers and Scada programs.

RS485 to USB converters now available.



🌃 Monitor 95					
Model 570 Version 0.3.01.00 Date 16-02-04 Type 3ph4W Voltage (V) 230.000 Current (A) 400.000 Power (kW) 276.000	Monitor / Log I 2 400.1 I 3 400.3 W Sum 276309 VA Sum 276306 VAR Sum 0.000 PF Avg -1.000	Quit Help M Factory Versior			
Monitor relay Change -> Status Show/Hide-> Demand Time 8	Pass Codes Resets General General Energy Registers Cal Enable Demand Calibrate Reset EEProm Node #	Start Pause Stop Master Code			
Demand Status 8 Stack Free 2 (min 2) Parity Errors 0 CRC Errors 0 EEProm 0K	Calibration Factors At 100% V1 1.095942 I1 1.127728 V2 1.096234 I2 1.125467 Clear V3 1.097045 I3 1.125399 Manual	Timer 00:00:00: 0 (s) Start Continue			
Map 3X Modbus TX >> 01 03 00 2E 00 0C 25 C6 Modbus RX << 01 03 18 3F 8C 47 D6 3F 8C 51 66 3F 8C 6B FC 3F 90 59 60 3F 90 0F 4D 3F 90					

Start Log User goes into the log screen and logging of up to 6 parameters can be performed. **Response Time** User can set response time. *Node* Node (address) can be set between 1 and 247.

PARAMETERS ASSIGNABLE TO RELAYS PARAMETERS MEASURED

- * Phase Voltage (V)
- * Phase Current (I)
- * Phase Balance (V)
- * Frequency (Hz)
- * Reverse Power. (-W)
- * Reverse VAr (-VAr)
- * System Active Power (W)
- * System Reactive Power (VAr)
- * Apparent Power per phase (VA)
- * System Apparent Power (VA)
- * Import Active Energy (W.h)
- * Export Active Energy (W.h)
- * Import Reactive Energy (VAr.h)
- * Export Reactive Energy (VAr.h)
- * Apparent Energy (VA.h)
- * Ampere Energy (A.h)
- * Amp Demand (Ad)
- * Import Watt Demand (Wd)
- * Export Watt Demand (Wd)
- * V A Demand (VAd)

SYSTEMS

PRODUCT CODE

Single PhaseM570-PR1Single Phase 3 wireM570-PR1-33 phase 3 wire unbalanced loadM570-PR43 phase 4 wire unbalanced loadM570-PR9

MEMORY

All data including, energy registers, current and voltage ratios relay trip points and calibration data is stored in a non volatile eeprom. Under power down (power loss) conditions this data is retained.

APPLICATIONS

Applications include generating sets, switchgear, management systems, distribution feeders, control panels, UPS systems, process control, generating systems, power management and control.

AUTO-CONFIGURABLE

The PowerRelay communication port is auto-configurable meaning that when connected to an existing Modbus network it will automatically set Baud rate, Parity and Stop bits.

A green LED is provided to indicate power is present, and the unit is communicating correctly.

- * Phase Voltage (V)
- * Line Voltage (V)
- * Phase Current (I)
- * Frequency (Hz)
- * Active Power per phase (W)
- * System Active Power (W)
- * Reactive Power per phase (VAr)
- * System Reactive Power (VAr)
- * Apparent Power per phase (VA)
- * System Apparent Power (VA)
- * Import Active Energy (W.h)
- * Export Active Energy (W.h)
- * Import Reactive Energy (VAr.h)
- * Export Reactive Energy (VAr.h)
- * Apparent Energy (VA.h)
- * Ampere Energy (A.h)
- * Power Factor per phase (P.F.)
- * System Power Factor (P.F.)
- * Amp Demand (Ad)
- * Watt Demand (Wd)
- * VA Demand (VAd)
- * Maximum Amp Demand (Max Ad)
- * Maximum Watt Demand Import (Max Wd)
- * Maximum Watt Demand Export (Max Wd)
- * Maximum VA Demand (Max VAd)
- * Neutral Current

OUTPUT RELAYS

Relay type: Single Pole A or B contact. Material: AgSnInO AC Rating: 250V 5A DC Rating: 30V 1A Relay's R1 and R2 are normally open Relay R3 is normally closed. Note contact operation of R1, R2 and R3 can be changed on request when ordering. Relay R4 is normally open and closes when unit counts energy etc. Terminal 19 is common to all 4 relays

RELAY ACCURACY

Specified (a) 23° C 10%-Un 10%-In Voltage & Current:-Accuracy $\pm 1\%$ of range Resolution $\pm 1\%$ Frequency:-Accuracy $\pm 0.02Hz$ Repeatability $\pm 0.02Hz$ All other Parameters:-Accuracy $\pm 2\%$ Repeatability $\pm 1\%$

GENERAL SPECIFICATION

INPUT	
Rated Un	Direct connected voltages between
	57.8 and 600 V. Specify nominal.
Range	10-120% Un
Overload	1.5 x Un cont. 4 x Un for 1 sec
Rated In	1 or 5 amp
Range	10-120% In
Burden	0.5VA per phase Volts & Amps
Overload	4 x In continuous. 50 x In for 1sec
Frequency	50 / 60 Hz nominal range 45/65Hz

MODBUS ACCURACY

Specified (a) 23°C 10%-Un 10%-InParameters unless statedClass 0.3% to IEC 688Volts and AmpsClass 0.25% to IEC 688FrequencyClass 0.1Hz to IEC 688Power FactorClass 1.0% to IEC 688Active & Reactive Energy 1% of reading IEC1036

INSULATION

Test Voltage	4 kV RMS 50 Hz for 1 min
0	Inputs/Case/Auxiliary/Output
	3kV RS485 / Outputs
	1.5kV Relay
Impulse Test	EMC 5kV transient complying
	with IEC 801 / EN 55020 HF
Surge withstand	IEC 801 / EN55020
	ANSI C37.90A
Interference	EHF 2.5 kV 1Mhz
	complying with IEC 255-4
Protection Class	II complying with IEC348

APPLIED STANDARDS

General	IEC 688 BSEN60688,
	BS4889, IEC 359
EMC	Emissions BSEN50081/1
	Immunity BSEN50082/2
Safety	IEC 1010, BSEN601010

AUXILIARY

AC voltage	115, 230, 277, 400 volts (±15%)
DC voltage	12, 24, 48, 110, 125, volts (±15%)
1990 - 1996 - 1992 - 1993 - 1986 -	Specify nominal voltage.

ENVIRONMENTAL

Working Temperature	-25 to +70 deg C
Storage Temperature	-40 to +85 deg C
Temperature Coefficient	0.01% per deg C

APPROVALS UL, C-UL, CSA

CASE DIMENSIONS



CONNECTION DIAGRAMS





Single Phase

Single Phase 3 Wire





3 Ph 3 W Unbalanced Load

3 Ph 4 W Unbalanced Load



For more information, contact Panel Components & Systems, Inc. Phone: +1 (973) 448-9400 Website: www.pc-s.com